

Test for Chlorine Sanitizer



■ Sink: Immerse one inch of test strip in solution

Warewasher: After sanitizing cycle hold the test strip against the wet ware

■ Remove immediately

■ Blot strip with paper towel

■ Compare pad to the color chart

Keep out of sunlight

Keep vial closed when not in use

Do not use if papers are discolored

Use dry fingers to remove test strip from vial



These instructions are for LaMatte item code 4250-BJ. Approximate color values are shown, accurate readings are to be made using the key provided with the test strips.